

ASSEMBLY & INSTALLATION INSTRUCTIONS FOR #25024

Please read carefully and save these instructions, as you may need them at a later date

CAUTION

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock

GENERAL

you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician. All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If

referencing the illustrations on the installation instructions Remove the fixture and the mounting package from the box and make sure that no parts are missing by

ASSEMBLY AND INSTALLATION

- SUPPLY GROUND WIRE (8) out-from the OUTLET BOX (1) and attach the MOUNTING BRACKET (2) NIPPLE(4) but do not tighten the 1/8" IPS HEX NUTS (5). Pull the SUPPLY WIRES (9 & 11) and the MOUNTING BRACKET (2) and thread both 1/8" IPS HEX NUT(5) several turns onto each end of the Take the parts out of the mounting package. Screw the end of the NIPPLE (4) into the center hole of the MOUNTING SCREWS (3) provided. (See Fig. 1) assembly to the OUTLET BOX (1) using the slotted holes of the MOUNTING BRACKET (2) and the
- the outside threads on the SCREW COLLAR LOOP (6) is centered (aligned) with the surface of the CANCPY over the OUTLET BOX (1) and adjust the SCREW COLLAR LOOP (6) and NIPPLE (4) until the midpoint of Thread the SCREW COLLAR LOOP (6) onto the bottom end of the NIPPLE (4). Place the CANOPY (15) BRACKET (2) and the SCREW COLLAR LOOP (6). (See Fig. 1) Remove the CANOPY (15) and tighten both 1/8" IPS HEX NUTS (5) down on the MOUNTING
- Thread the FIXTURE LOOP(18) onto the NIPPLE(19) till tight. Pull the arms to they are evenly spaced, fix it onto the JUNCTION BOX(20) with the NUT SCREW(21). (See Fig. 2)
- Open up the end links of the CHAIN (17) and attach one end of the CHAIN (17) onto the FIXTURE LOOP attach the other end of the CHAIN (17) to the SCREW COLLAR LOOP (6). Close the ends of the chain links (See Fig. 1 and 2) Slide the THREADED RING (16) and the CANOPY (15) onto the CHAIN (17) (in that order) and
- S Unravel the fixture lead wires(10 and 12) and FIXTURE GROUND WIRE (7) and thread them through every other link of the CHAIN (17) starting with the chain link attached to the FIXTURE LOOP (18). Feed the fixture lead wires(10 and 12) and FIXTURE GROUND WIRE (7) through the SCREW COLLAR LOOP (6) and NIPPLE (4) assembly. Pull the fixture lead wire(10 and 12) and the FIXTURE GROUND WIRE (7) upward to remove any excess slack. (See Fig. 1)
- 6 Attach the power supply wires to the fixture lead wires by connecting the BLACK SUPPLY WIRE (9) to the SMOOTH FIXTURE LEAD WIRE (10) and the WHITE SUPPLY WIRE (11) to the RIBBED FIXTURE MOUNTING BRACKET (2). (Note: Be sure to provide an extra 3" length of the GROUND WIRE(7).) CONNECTOR (13). Place wiring and connections inside the OUTLET BOX (1). (See Fig. 1) Connect the remaining FIXTURE GROUND WIRE (7) to the SUPPLY GROUND WIRE (8) using a WIRE LEAD WIRE (12). Loop the FIXTURE GROUND WIRE (7) around the GROUND SCREW (14) of the

7. FIXTURE GROUND WIRE 1/8" IPS HEX NUT

> 13. WIRE CONNECTOR 12. RIBBED FIXTURE LEAD

20. JUNCTION BOX 21. NUT SCREW 22. SOCKET 23. GLASS SHADE 24. SOCKET RING

14, GROUND SCREW

16. THREADED RING 15. CANOPY

SUPPLY GROUND WIRE

ASSEMBLY AND INSTALLATION (Continued)

- Slide the CANOPY (15) and the THREADED RENG(16) up the CHAIN(17). Place the CANOPY (15) over the OUTLET BOX (1) and secure it in place by screwing the THREADED RING (16) onto the SCREW COLLAR LOOP (6).(See Fig. 1)
- 00 Slide the GLASS SHADE(23) over the SOCKET(22), secure with the SOCKET RING(24)
- 10. Screw light bulbs into the lamp sockets and make sure they do not exceed the maximum wattage specified on the fixture's wattage rating label, MAXIMUM 60W.

